OMNISPORT® HS-200 HORN/GUN AND PUBLIC ADDRESS SYSTEM



The OmniSport HS-200 horn start and public address system is a complete starting solution for aquatics and track. Features include a rechargeable battery that will last for more than 15 hours on a full charge. The recall feature can be enabled or disabled depending on the officials' preference. The HS-200 can be programmed to sound a typical start tone or emulate a gun sound.

PRODUCT SPECIFICATIONS

DIMENSIONS: Height 12", Width 8", Depth 14" (305 mm, 203 mm, 356 mm)

WEIGHT: 14 lb (6.4 kg)

POWER: 120 V, or rechargeable battery (15 hour life on full charge)

CONSTRUCTION: Durable, lightweight aluminum

QUALITY

COMMITMENT PLAN: Exclusive two-year Daktronics Gold[™] plan in the U.S. and Canada (see SL05766

for more information)

FEATURES: 1. Internal 40 Watt Speaker sounds voice and start tone signals.

2. LED Indicators show start recall, battery charging, and battery full/low status.

3. Separate Speaker Connections are dedicated outputs to auxiliary and lane speakers for maximum perforance and flexibility.

speakers for maximum performance and nexibility

4. Start Output provides both normally open and normally closed contacts for connection to all brands of timings systems.

connection to all brands of tillings systems.

 $5.\,360\,degree\,Stobe\,Light\,is\,easily\,viewable\,indoor\,and\,outdoor\,for\,all\,athletes$

and officials.

6. Separate Volume Control for independent control between the main/auxiliary

speakers and the lane speakers.

ACCESSORIES: 1. Backstroke Flagpole Mounting Bracket

2. Tripod

3. Remote Strobe


4. Auxiliary Speaker

5. Individual Lane Speakers

HS-200 PRODUCT SPECIFICATIONS (CONTINUED)

HS-200-R OPTION:

- 1. HS-200-R is FCC approved.
- 2. HS-200-R includes an internal receiver.
- 3. The standard microphone plugs into the belt pack or directly into the HS-200-R. The belt pack is worn by the official allowing them the freedom to position themselves in the most effective location.
- 4. LED indicators on the HS-200R show the selected channel, the voice activation and identify interference (noise).
- 5. A channel button is on the belt pack and on the unit to change the current channel. There are 8 channels to select from.



GoldSM and OmniSport[®] are registered trademarks of Daktronics, Inc.